



# Bilbao


Montageanleitung · Instruction Manual · Instructions d'installation · Instrucciones de instalación · Istruzioni per l'installazione · Szerelési útmutató · Monteringsanvisning · Installatie-instructies · Инструкция по монтажу

BO 5213162



BO 5213163



①



②



8, 10, 12 mm

# Bohle Worldwide

## Germany

Bohle AG · Head Office  
42781 Haan  
T +49 2129 5568-100  
info@bohle.de

---

## Austria | Hungary Slovenia

Bohle GmbH  
1230 Wien  
T +43 1 804 4853-0  
info@bohle.at

---

## Benelux

Bohle Benelux B.V.  
3905 LX Veenendaal  
T +31 318 553151  
info@bohle.nl

---

## China

Bohle Trading Co., Ltd  
Tianhe District, Guangzhou  
T +86-20-38105870  
jiang.du@bohle.de

---

## Croatia

Bohle d.o.o.  
51000 Rijeka  
T +385 051-329-566  
info@bohle.hr

---

## Estonia

Bohle Baltic  
13619 Tallinn  
T +372 6112-826  
info@bohle.ee

---

## France

Bohle AG · Departement Français  
42781 Haan, Germany  
T +49 2129 5568-222  
france@bohle.de

---

## Italy

Bohle Italia s.r.l.  
20080 Vermezzo (MI)  
T +39 02 94967790  
info@bohle.it

---

## Russia

Bohle Москва  
108811 Москва  
T +7 495 230-94-00  
info@bohle.ru

---

## Russia

Bohle Санкт Петербург  
198020 Санкт Петербург  
T +7 812 4452792  
info@bohle.spb.ru

---

## Spain | Portugal

Bohle Complementos del Vidrio S.A.U.  
08907 L'Hospitalet (Barcelona)  
T +34 932 615 361  
info@bohle.es

---

## South Africa

Bohle Glass Equipment (Pty) Ltd.  
2125 Gauteng  
T +27 11 792-6430  
info@bohle.co.za

---

## Sweden

Bohle Scandinavia AB  
14175 Kungens Kurva  
T +46 8 449 57 50  
info@bohle.se

---

## United Kingdom Ireland

Bohle Ltd.  
Dukinfield, Cheshire, SK16 4PP  
T +44 161 3421100  
info@bohle.ltd.uk

---

## USA

Bohle America  
Charlotte, NC 28273  
T+ (877) 678-2021  
info@bohle-america.com

---

Bohle AG  
Dieselstraße 10  
D - 42781 Haan

T +49 2129 5568-100  
F +49 2129 5568-281

info@bohle.de  
www.bohle.com